

Motive Products Application Guide

****All vehicles that use the Custom 1106, 1107 or 1108 adapters can also use the 1101 Universal Round**

Vehicle Make	Model	Year	Bleeder
Acura	All	1985+	MOT-1101
Alfa Romeo	All	All	MOT-1109/1100**
AMC	All	1964-1988	MOT-1105
Audi	All	All	MOT-1109/1100**
BMW	All	All	MOT-1109/1100**
Buick	All	1967-1980	MOT-1105
Buick	Century	1973-1984	MOT-1105
Buick	Century	1987-1994	MOT-1101
Buick	GS	1967-1977	MOT-1105
Buick	Le Sabre, Park Avenue, Riviera	1991-2001	MOT-1108/1101*
Buick	Regal	1967-1978	MOT-1105
Buick	Regal	1988-1990	MOT-1101
Buick	Regal, Skyhawk, Skylark, Somerset , Gran Sports	1991-2005	MOT-1108/1101*
Buick	Skyhawk, Skylark, Somerset	1987-1991	MOT-1101
Cadillac	Allante, Concours, El Dorado , Seville , (w/ABS)	1986-1995	MOT-1101
Cadillac	Brougham, Fleetwood	1967-1980	MOT-1105
Cadillac	Cimмерon	1987-1988	MOT-1101
Cadillac	CTS	2001+	MOT-1108/1101*
Cadillac	Deville	1994-2001	MOT-1108/1101*
Cadillac	El Dorado , Concours, Seville	1967-1978	MOT-1105
Cadillac	El Dorado	1996+	MOT-1108/1101*
Cadillac	Fleetwood (w/ABS)	1987-1993	MOT-1101
Cadillac	Fleetwood (Diesel)	1981-1986	MOT-1105
Cadillac	Northstar	1996+	MOT-1108/1101*
Cadillac	Seville SLE, STS	1996+	MOT-1108/1101*
Cadillac	SRX, XLR	2003+	MOT-1108/1101*
Chevrolet	Baretta, Cavalier, Corsica	1987-1995	MOT-1101
Chevrolet	Blazer	1999+	MOT-1108/1101*
Chevrolet	Camaro	1967-1991	MOT-1105
Chevrolet	Camaro	1993+	MOT-1108/1101*
Chevrolet	Caprice, Impala	1967-1980	MOT-1105
Chevrolet	Cavalier	1996+	MOT-1108/1101*
Chevrolet	Chevelle, El Camino, Malibu , Monte Carlo , Nova, Vega	1967-1977	MOT-1105
Chevrolet	Chevette, Monsa	1975-1987	MOT-1105
Chevrolet	Corvette	1967-1982	MOT-1105
Chevrolet	Corvette	1984-1991	MOT-1101
Chevrolet	Corvette	1996+	MOT-1108/1101*
Chevrolet	El Camino, Malibu , Monte Carlo (Diesel)	1982-1988	MOT-1105
Chevrolet	Lumina (except Z 34 or 1100 Z4)	1990-2001	MOT-1108/1101*
Chevrolet	Nova	1985-1988	MOT-1101

Motive Products Application Guide

****All vehicles that use the Custom 1106, 1107 or 1108 adapters can also use the 1101 Universal Round**

Chevrolet	Spectrum, Sprint	1985-1992	MOT-1101
Chevrolet	Silverado, Tahoe	2001+	MOT-1108/1101*
Chevrolet	Transport	1999+	MOT-1108/1101*
Chevrolet, GMC	C, K, R, V 30, 3500	1967-1987	MOT-1105
Chevrolet, GMC	Sonoma, Suburban, V 10, S10, 1500, 2500	1967-1980	MOT-1105
Chevrolet, GMC	Sonoma, Suburban, C, K, R, V 10, S10, 1500 (w/metal)	1981-2001	MOT-1105
Chevrolet, GMC	Astro, Safari	1985-2001	MOT-1105
Chevrolet, GMC	Blazer, Caballero, Jimmy	1976-1980	MOT-1105
Chevrolet, GMC	Blazer, Caballero, Jimmy (Diesel)	1981-1991	MOT-1105
Chevrolet, GMC	Tracker	1989-1990	MOT-1101
Chevrolet, GMC	Yukon	1976-1990	MOT-1105
Chevrolet, GMC	Yukon (Diesel)	1981-1991	MOT-1105
Chevrolet, GMC	Vans (1/2 ton, 3/4 ton, 1 ton)	1967-1984	MOT-1105
Chevrolet, GMC	Vans (3/4 ton, 1 ton) w/ metal reservoir	1985-2001	MOT-1105
Chrysler	All	1967-1978	MOT-1105
Chrysler	All with single reservoir cap	1993-2001	MOT-1101
Chrysler	300M	1999+	MOT-1107/1101*
Chrysler	Concorde LX	1999-2002	MOT-1107/1101*
Chrysler	Crossfire	1999-2002	MOT-1107/1101*
Chrysler	Grand Voyager	1999+	MOT-1107/1101*
Chrysler	New Yorker	All	MOT-1107/1101*
Chrysler	PT Cruiser	All	MOT-1101
Chrysler	Sebring	2001+	MOT-1107/1101*
Dodge	All except:	1967-1977	MOT-1105
	1971-1975 Colt		MOT-
Dodge	All w/ metal reservoir	1978	MOT-1105
Dodge	All except some Caravan	1994-2001	MOT-1101
Dodge	Colt	1971-1975	MOT-1101
Dodge	Colt (except Colt Mini Van)	1978-2001	MOT-1101
Dodge	D100/150 w/ metal reservoir	1967-1993	MOT-1105
Dodge	D200/050/300/350 w/ metal reservoir	1967-1993	MOT-1105
Dodge	Neon	2001	MOT-1107/1101*
Dodge	Ram 1500, Dakota w/ metal reservoir	1967-1981	MOT-1105
Dodge	Ram 2500, 3500 w/ metal reservoir	1967-1993	MOT-1105
Dodge	Ram 50, Raider	1979-1993	MOT-1101
Dodge	Rampage, Ramcharger w/ metal reservoir	1974-1979	MOT-1105
Dodge	Stealth	1971-1975	MOT-1101
Dodge	Stealth	1978-2001	MOT-1101
Dodge	Stratus	1999+	MOT-1107/1101*
Dodge	W100/150 w/ metal reservoir	1967-1981	MOT-1105
Dodge	2000 GTX	1978-2001	MOT-1101

Motive Products Application Guide

****All vehicles that use the Custom 1106, 1107 or 1108 adapters can also use the 1101 Universal Round**

Dodge Van	B Series w/ metal reservoir	1967-1980	MOT-1105
Eagle	All	1988-2001	MOT-1101
Ford	All w/ metal reservoir	1967-1987	MOT-1105
Ford	All except Mystique, Probe '94-'99	1988-2001	MOT-1106/1107/
			MOT-
			MOT-1101*
Ford	Aerostar	1993+	MOT-1107/1101*
Ford	Escort Exp. w/ metal reservoir	1983-1990	MOT-1105
Ford	Escort	1991+	MOT-1107/1101*
Ford	Fiesta	1978-1980	MOT-1109/1100**
Ford	Mystique, Probe	1994-1999	MOT-1109/1100**
Ford	Courier	1972-1982	MOT-1109/1100**
Ford Truck	All w/ metal reservoir	1967-1986	MOT-1109/1100**
Ford Truck	All except Aerostar	1987-2001	MOT-1106/1107/
			MOT-
			MOT-1101*
Geo	Metro	1996-2001	MOT-1101
GTO	All	2004-2005	MOT-1105
Honda	All	1973-2001	MOT-1101
Hyundai	All except Pony, 1992-93 Sonata	1985-2001	MOT-1101
Hyundai	Accent	1995+	MOT-1107/1101*
Hyundai	Elantra	2001+	MOT-1107/1101*
Hyundai	Sonata	1995+	MOT-1107/1101*
Hyundai	Stellar	1985-1987	MOT-1109/1100**
International	All trucks (Light Duty)	1967-1980	MOT-1105
Isuzu	All	1984-2001	MOT-1101
Jeep	Cherokee, Grand Cherokee, Wagoneer	1967-1980	MOT-1105
Jeep	Cherokee, Grand Cherokee, Wagoneer w/ metal reservoirs	1984-1992	MOT-1105
Jeep	Cherokee	1995	MOT-1107/1101*
Jeep	Cherokee, Grand Cherokee, Wagoneer	1995-2001	MOT-1101
Jeep	CJ, YJ, Comanche	1967-1994	MOT-1105
Jeep	CJ, YJ, Comanche w/ plastic reservoir	1995-2001	MOT-1101
Jeep	CJ, YJ, Comanche w/ metal reservoir	1995-2001	MOT-1105
Jeep	J10, J20	1967-1980	MOT-1105
Land Rover/ Range Rover	All	1970-2001	MOT-1109/1100**
Land Rover/ Discovery II	All	2000	MOT-1101
Lincoln	All	1967-1989	MOT-1105
Lincoln	All	1990-2001	MOT-1101
Mazda		121 1995+	MOT-1107/1101*
Mazda	MX6 626 (w/ 1 3/4" screw on reservoir cap)	1979-1999	MOT-1109/1100**
Mazda	All others including Miata	All	MOT-1101

Motive Products Application Guide

****All vehicles that use the Custom 1106, 1107 or 1108 adapters can also use the 1101 Universal Round**

Mazda	MPV	1999+	MOT-1107/1101*
Mazda	Tribute	2001+	MOT-1108/1101*
Mercedes Benz	All	All	MOT-1109/1100**
Mercury	All w/ metal reservoir	1967-1999	MOT-1105
Mercury	Capri	1971-1977	MOT-1109/1100**
Mercury	Capri	1979-1985	MOT-1105
Mercury	Contours	1995-2001	MOT-1109/1100**
Mercury	Merkur	1985-2001	MOT-1109/1100**
Mercury	Tracer	1991-1993	MOT-1109/1100**
Mercury	All others	1988-2001	MOT-1107/1101*
Mitsubishi	All	All	MOT-1101
Mitsubishi	121 Mitsubishi Lancer	2003	MOT-1107/1101*
Mitsubishi	Outlander	All	MOT-1107/1101*
Mitsubishi	All Wagons	1999+	MOT-1107/1101*
Nissan	All	1970-2001	MOT-1101
Nissan	100 SX	1995+	MOT-1107/1101*
Nissan	200 SX	All	MOT-1107/1101*
Nissan	Maxima	1995+	MOT-1107/1101*
Oldsmobile	Achieva	1992-2005	MOT-1108/1101*
Oldsmobile	Aurora	1995-2001	MOT-1108/1101*
Oldsmobile	Calais , Cutlass, Cierra	1987-1989	MOT-1101
Oldsmobile	Cutlass, Calais , Cierra	1990-2005	MOT-1108/1101*
Oldsmobile	Cutlass, Supreme, Vista Cruiser	1967-1973	MOT-1105
Oldsmobile	Cutlass, Supreme, Vista Cruiser	1974-1981	MOT-1101
Oldsmobile	Cutlass, Supreme, Vista Cruiser (Diesel)	1982-1987	MOT-1105
Oldsmobile	Firenza	1987-1999	MOT-1101
Oldsmobile	Intrigue	1998+	MOT-1108/1101*
Oldsmobile	Omega	1973-1979	MOT-1105
Oldsmobile	Passport, Optima	1988-1991	MOT-1101
Oldsmobile	Regency, Royale (Diesel)	1981-1985	MOT-1105
Oldsmobile	Starfire	1975-1980	MOT-1105
Oldsmobile	Tornado	1967-1978	MOT-1105
Oldsmobile	Tornado (Diesel)	1982-1985	MOT-1105
Oldsmobile	88, 98, Custom, Cruiser, Delta, Regency Royale	1967-1980	MOT-1105
Oldsmobile	88, 98, Custom, Cruiser, Delta, Regency Royale	1991-1999	MOT-1108/1101*
Peugeot	All	All	MOT-1109/1100**
Plymouth	All	1967-1978	MOT-1105
Plymouth	All	1995-2001	MOT-1101
Plymouth	Laser	1990-1993	MOT-1101
Plymouth	Neon	1994-1995	MOT-1101
Plymouth	Voyager	1987	MOT-1105
Pontiac	Acadian	1976-1987	MOT-1105
Pontiac	Astre, Beaumont	1967-1978	MOT-1105
Pontiac	Asuna, Sunfire	1992-1999	MOT-1108/1101*
Pontiac	Bonneville, Catalina w/ metal reservoir	1967-1986	MOT-1105

Motive Products Application Guide

****All vehicles that use the Custom 1106, 1107 or 1108 adapters can also use the 1101 Universal Round**

Pontiac	Fiero, Firebird,	1967-1980	MOT-1105
			MOT-
	Trans Am		MOT-
Pontiac	Fiero, Firebird,	1993-2001	MOT-1108/1101*
			MOT-
	Trans Am		MOT-
Pontiac	Grand Am, Lemans	1976-1980	MOT-1105
Pontiac	Grand Am, Lemans, J2000 Sunfire, Phoenix , Sunbird	1987-1991	MOT-1101
Pontiac	Grand Am	1991-2005	MOT-1108/1101*
Pontiac	Grand Prix	1967-1981	MOT-1105
Pontiac	Grand Prix (Diesel)	1982-1984	MOT-1105
Pontiac	Grand Prix	1988-1999	MOT-1101
			MOT-
	(except 1994-95 GT)		MOT-
Pontiac	Grand Prix	1992-1996	MOT-1108/1101*
Pontiac	GTO	1967-1978	MOT-1105
Pontiac	J2000, Sunfire w/ metal reservoir	1976-1980	MOT-1105
Pontiac	J2000 Sunbird	1992-1994	MOT-1108/1101*
Pontiac	Parisienne, Phoenix , Safari, Sunbird w/ metal reservoir	1976-1980	MOT-1105
Pontiac	Parisienne, Safari (Diesel)	1981-1985	MOT-1105
Pontiac	Sunburst Tempest	1985-1991	MOT-1101
Pontiac	Sundance	1996-1999	MOT-1108/1101*
Pontiac	Sunfire	1995-1998	MOT-1108/1101*
Pontiac	Transport Van	1991-1999	MOT-1101
Pontiac	Ventura	1967-1978	MOT-1105
Pontiac		6000 1987-1991	MOT-1101
Porsche	All	All	MOT-1109/1100**
Renault	All	1972-1989	MOT-1109/1100**
Saab	All	1972-1994	MOT-1109/1100**
Saturn	All	1992-2001	MOT-1108/1101*
Subaru	All	All	MOT-1101
Subaru	Forrester	1999+	MOT-1107/1101*
Subaru	Impreza	1998+	MOT-1107/1101*
Subaru	Outback	1989+	MOT-1107/1101*
Suzuki	All	1979-1999	MOT-1101
Toyota	All, except some late model 4runners (please call)	All	MOT-1101
Volvo	All, except S40, V40	1972-2001	MOT-1109/1100**
Volvo	S40, V40	All	MOT-1101
VW	All water-cooled	All	MOT-1109/1100**
VW	All air-cooled	All	MOT-1104

* All vehicles that use the Custom 1106, 1107 or 1108 adapters can also use the 1101 Universal Round Adapter.